

# Panasonic

Digital Proprietary Telephones

## *Quick Reference Guide*

Model **KX-T7625 KX-T7630**  
**KX-T7633 KX-T7636**

### ***Important Information***

---

**When using the KX-T7600 series, keep the following conditions in mind.**

- If there is any problem, unplug the extension line and connect a known working phone. If the known working phone operates properly, have the defective phone repaired by a specified Panasonic Factory Servicenter. If the known working phone does not operate properly, check the KX-TDA series Business Telephone Systems and the internal extension wiring.
- Keep the unit away from heating appliances and electrical noise generating devices such as fluorescent lamps, motors and televisions. These noise sources can interfere with the performance of the unit.
- This unit should be kept free of dust, moisture, high temperature (more than 40 °C [104 °F]) and vibration, and should not be exposed to direct sunlight.
- Do not use benzine, thinner, or the like, or any abrasive powder to clean the cabinet. Wipe it with a soft cloth.
- Do not use any handset other than a Panasonic handset.
- Do not disassemble this product. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians.
- When a failure occurs, which exposes any internal parts, disconnect the telephone line cord immediately and return this unit to servicenter.
- Never attempt to insert wires, pins, etc., into the vents or other holes of this unit.

#### **WARNING:**

**TO PREVENT THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**

**THIS HANDSET EARPIECE IS MAGNETIZED AND MAY RETAIN SMALL FERROUS OBJECTS.**

#### **IMPORTANT NOTICE:**

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for use in an emergency.

**Thank you for purchasing the Panasonic KX-T7600 series, Digital Proprietary Telephone. Please read this manual carefully before using this product and save this manual for future use.**

This manual is designed to be used with your Digital Proprietary Telephone and a Panasonic KX-TDA series Business Telephone System.

**Note:** In this manual, the suffix of each model number is omitted.

# Table of Contents

<b>Features for the Digital Proprietary Telephones.....</b>	<b>Setting Features .....</b>	<b>9</b>
<b>2</b>	<b>Location of Controls .....</b>	<b>11</b>
<b>Features List .....</b>	<b>Connection.....</b>	<b>13</b>
<b>3</b>	<b>Setting .....</b>	<b>13</b>
<b>Using the Display Proprietary Telephone..</b>	<b>Tilt Angle Adjustment .....</b>	<b>14</b>
<b>5</b>	<b>Wall Mounting.....</b>	<b>14</b>
Using the Call Log or Directories .....	<b>Installing the KX-T7601/KX-T7603 .....</b>	<b>15</b>
5		
Accessing the System Features .....		
6		
Entering Characters.....		
7		
<b>Settings on the Programming Mode.....</b>		
<b>9</b>		

## Before Initial Use


### When you ship the product

Carefully pack and send it prepaid, adequately insured and preferably in the original carton. Attach a postage-paid letter, detailing the symptom to the outside of the carton. DO NOT send the product to the Executive or Regional Sales offices. They are NOT equipped to make repairs.

### Product service

Panasonic Factory Servicenters for this product are listed in the servicenter directory. Consult your authorized Panasonic dealer for detailed instructions.

**Accessories (included) For extra orders, call toll-free: 1-800-332-5368.**




















<input type="checkbox"/> Handset    <p style="text-align: center;">One</p>	<p style="text-align: center;">Handset Cord</p>          <p style="text-align: center;">One</p>	<p style="text-align: center;">Telephone Line Cord</p>          <p style="text-align: center;">One</p>	<p style="text-align: center;">Wall Mounting Adaptor *</p>          <p style="text-align: center;">One</p>
---	---	--	--

\* This telephone comes with the wall mounting adaptor already attached. To remove the adaptor for desktop operation, push the adaptor toward the top of the unit while pressing the two tabs.














## Features for the Digital Proprietary Telephones

Model	Description
<b>KX-T7636*</b>	DPT with Speakerphone, 6-Line Display with Backlight (24-CO)
<b>KX-T7633*</b>	DPT with Speakerphone, 3-Line Display with Backlight (24-CO)
<b>KX-T7630</b>	DPT with Speakerphone, 3-Line Display (24-CO)
<b>KX-T7625</b>	DPT with Speakerphone (24-CO)

\* Optional USB Module and Add-on Key Module are available.

Feature	Operation	
<b>Making Calls</b>		
Calling	<b>To an extension</b>  ► <b>extension no.</b> ►	<b>To an</b>
Redial	 ►	
	 ► <b>quick dial no.</b> ► 	
One-touch Dialing	<b>To store</b>  ►  ► <b>2</b> ► 	
	<b>To dial</b>  ►  — assigned as a One-touch Dialing button	
	 ► <b>0</b> ► 	
	<b>To store</b>  ► <b>3</b> <b>0</b> ► <b>personal dial no. (2)</b>	
	<b>To dial</b>	
Doorphone Call	 ► <b>doorphone no. (2 digits)</b>	
Automatic Callback Busy	<b>To set</b> <i>While hearing a busy tone</i> <b>6</b> 	<b>To cancel</b>  ► <b>4</b> <b>6</b> 
	<b>To answer from an idle extension</b> <i>While hearing a callback ring</i>  	<b>To answer from an idle outside line</b> <i>While hearing a callback ring</i>  ► <b>outside phone no.</b> ►

# Features List

Feature	Operation						
<b>Useful Features</b>							
Call Pickup	▶						
Sending a Call Waiting Tone	<i>While hearing a busy tone</i> <span style="border: 1px solid black; padding: 2px;">1</span> ▶ Wait for an answer. ▶ 						
Message Waiting	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%; text-align: center; vertical-align: middle;">Caller</td> <td style="text-align: center;"> <b>To leave a message waiting indication</b>  <i>When the called extension is busy or does not answer</i>   </td> </tr> <tr> <td style="text-align: center; vertical-align: middle;">Called extension</td> <td style="text-align: center;"> <b>To call back</b>   ▶ ▶  </td> </tr> </table>	Caller	<b>To leave a message waiting indication</b> <i>When the called extension is busy or does not answer</i> 	Called extension	<b>To call back</b>  ▶ ▶ 		
	Caller	<b>To leave a message waiting indication</b> <i>When the called extension is busy or does not answer</i> 					
Called extension	<b>To call back</b>  ▶ ▶ 						
Log-in/Log-out	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center; vertical-align: middle;"></td> <td style="width: 60%; text-align: center;"> <span style="border: 1px solid black; padding: 2px;">*</span> <span style="border: 1px solid black; padding: 2px;">7</span> <span style="border: 1px solid black; padding: 2px;">3</span> <span style="border: 1px solid black; padding: 2px;">6</span> <span style="border: 1px solid black; padding: 2px;">1</span> For Log-in                 </td> <td style="width: 30%; text-align: center; vertical-align: middle;">[ Specified ]</td> </tr> <tr> <td></td> <td style="text-align: center;"> <span style="border: 1px solid black; padding: 2px;">*</span> <span style="border: 1px solid black; padding: 2px;">0</span> For Log-out                 </td> <td style="text-align: center; vertical-align: middle;">[ All ]</td> </tr> </table>		<span style="border: 1px solid black; padding: 2px;">*</span> <span style="border: 1px solid black; padding: 2px;">7</span> <span style="border: 1px solid black; padding: 2px;">3</span> <span style="border: 1px solid black; padding: 2px;">6</span> <span style="border: 1px solid black; padding: 2px;">1</span> For Log-in	[ Specified ]		<span style="border: 1px solid black; padding: 2px;">*</span> <span style="border: 1px solid black; padding: 2px;">0</span> For Log-out	[ All ]
	<span style="border: 1px solid black; padding: 2px;">*</span> <span style="border: 1px solid black; padding: 2px;">7</span> <span style="border: 1px solid black; padding: 2px;">3</span> <span style="border: 1px solid black; padding: 2px;">6</span> <span style="border: 1px solid black; padding: 2px;">1</span> For Log-in	[ Specified ]					
	<span style="border: 1px solid black; padding: 2px;">*</span> <span style="border: 1px solid black; padding: 2px;">0</span> For Log-out	[ All ]					

## ◆◆ **Using the Call Log or Directories**

You can make a call with the call log or directories as follows:

- Outgoing Call Log**
- Incoming Call Log**
- Extension Number Directory**
- System Speed Dialing Directory**
- Personal Speed Dialing Directory**

### ◆ **Calling with a call log or directory**

Press **ENTER**. D(.)T79 l13.2( )JTJ/F2 (E)-10.3(n)5..

To cancel or exit, press **ESC** or **END**.

### **Entering the log information**

### **Storing the caller's information for the Personal Speed Dialing Directory**

- \* To enter characters, refer to "Entering Characters".

# ***Using the Display Proprietary Telephone***

---

***Storing names and numbers for the Personal Speed Dialing Directory***

## ***Accessing the System Features***

You can access these features with the “Feature Access” menu:

# Using the Display Proprietary Telephone

---

## ◆◆ Entering Characters

You can enter alphabetic characters and digits using the dialing buttons. Pressing a dialing button repeatedly displays different characters, as shown in the following tables. While entering characters, you can move the cursor with the left and right Navigator keys and delete a character with the TRANSFER button.

To toggle between Table 1 and Table 2, press the Soft button (S1) at any time while entering characters.

	1	2	3	4	5	6	7	8	9
1	!								
2									
3									
4									
5									
6									
7									
8									
9									
* 0									

# ***Using the Display Proprietary Telephone***

---

\*

## ***Setting Features***

You can customize many features of your telephone as shown in the following tables. Original settings are shown in the gray boxes. For later reference, place a check mark in

# Settings on the Program


Item	Programming Input	
Would you like to show a message on the caller's telephone display? (Absent Message)	[4] [0] [Absent Msg]	[0] message r [9]
Where are your incoming calls forwarded or refused? (Call Forwarding [FWD]/Do Not Disturb [DND])	( [5] [0] ) OR FWD/DND ( [5] [1] ) (for outside calls) [Fwd/DND CO] ( [5] [2] ) (for intercom calls) [Fwd/DND Ext]	[0] [1] [2] + de (max. 32 [3] + de (max. 32 [4] + de (max. 32 [5] + de (max. 32
Do you use the headset? (Headset Operation)	[6] [1] [Headset Mode]	[0] [1]
Would you like to set your extension PIN or change a stored extension PIN to new one? (Extension PIN [Personal Identification Number])	[9] [0] [Extension PIN]	extension (max. 10 + ENTER/ + same F stored ex PIN + nev (max. 10 + ENTER/ + same F
Would you like to prevent others from seeing your personal directory and call log? (Directory and Call Log Lock)	[9] [2] [Display Lock]	extension (max. 10 + [0] extension (max. 10 + [1]



- If nothing is entered for one minute in programming mode, the telephone returns to normal status.
- To exit the mode at any time, lift the handset.
- For further information on "Settings on the Programming Mode", refer to the Business Telephone System User Manual.

Business Telephone System, we strongly recommend that you use the system using the following points:

- Carefully maintain the secrecy of the PIN.
- Specify a complicated PIN as long and random as you can make it.
- Change the PIN frequently.



## ***Location of Controls***

---


**PAUSE:**



Used to insert a pause when storing a telephone number. This button also functions as the PROGRAM button when there is no PROGRAM button on your telephone.

.....

The telephone line cord (included)



→ Connect to a single line telephone for XDP or parallel connections (  ).



< Back view >

**CAUTION**  
Ensure the handset cord is inserted in the hook to prevent damage to the connector.

- Consult your dealer for more details about XDP.




**2** Insert the flat cable into the connector.

**3** Couple both hinges and slide in the unit.

**4** Push down the cover until it locks, and connect the USB cable to USB port.

The Add-on Key Module has 12 CO buttons. These buttons are used to seize an outside line, make a call using One-touch Dialing, or access certain features.



<with a KX-T7636>

**1** Open the cover.

**2** Attach the KX-T7603 to your telephone with screws.

**3** Insert the flat cable into the connector.

**4** Close the cover.

\* Please use a USB cable shorter than 3 m (3.28 yards).

**For your future reference**

SERIAL NO. _____ (found on the bottom of the unit)
DATE OF PURCHASE _____
NAME OF DEALER _____
DEALER'S ADDRESS _____ _____ _____ _____
DEALER'S TEL. NO. _____

**Copyright:**

This manual is copyrighted by Panasonic Communications Co., Ltd. (PCC). Under the applicable copyright laws, this manual may not be reproduced in any form, in whole or part, without the prior written consent of PCC and its licensee.

© 2003 Panasonic Communications Co., Ltd. All Rights Reserved.

**Panasonic Consumer Electronics Company**  
**Division of Matsushita Electric Corporation of America**  
One Panasonic Way  
Secaucus, NJ 07094

**Panasonic Sales Company**  
**Division of Matsushita Electric of Puerto Rico, Inc.**  
Ave. 65 de Infantería, Km. 9.5  
San Gabriel Industrial Park  
Carolina, Puerto Rico 00985

<http://www.panasonic.com/csd>